



INTERIOR DETAILING

BASIC TOOLS

MICROFIBER TOWELS
SOFT INTERIOR BRUSHES
STIFF CARPET BRUSH
INTERIOR SCRUB PAD

PRODUCTS:

CORIUM
SILK
LUSH
ZONE

ADVANCED TOOLS

STEAMER
HOT WATER EXTRACTOR
DUAL ACTION BRUSH
OZONE MACHINE

LEATHER, VINYL & PLASTIC

MOVE ON TO HIGHER STEPS IF THE PRIOR STEPS DON'T WORK

1. SPRAY CORIUM ON MICROFIBER TOWEL AND WIPE.
 - a. WRAP STEAMER HEAD WITH MICROFIBER TOWEL AND AGITATE SURFACE. WIPE CLEAN WITH MICROFIBER.
2. SPRAY CORIUM INTO A SOFT BRISTLE BRUSH AND AGITATE SURFACE TO RELEASE DIRT. THEN WIPE AWAY WITH MICROFIBER TOWEL.
3. SPRAY CORIUM ONTO SCRUB PAD AND SCRUB LIGHTLY. REMOVE WITH MICROFIBER TOWEL.

WHEN YOU FINISH CLEANING, MAKE SURE TO MOISTURIZE WITH LUSH. SIMPLY SPRAY THE MICROFIBER TOWEL AND APPLY. WIPE AWAY ANY EXCESS.

DOOR JAM KICK PANELS

START WITH BRUSH FIRST AS KICK PANELS TAKE THE MOST ABUSE

1. SPRAY BRUSH WITH CORIUM AND AGITATE SMALL AREAS
 - a. WIPE CLEAN WITH MICROFIBER TOWEL
2. IF THERE ARE MANY SCUFFS, USE A SCRUB PAD (WITH CORIUM) AND USE MEDIUM PRESSURE TO EVEN AND CLEAN THE PANEL
 - a. WIPE WITH A CLEAN MICROFIBER TOWEL

CARPET

PRODUCT: SILK

1. PRE-TREAT AREA WITH SILK. SIMPLY SPRAY AND LET SILK PENETRATE SURFACE
 - a. SCRUB WITH MICROFIBER TOWEL OR
 - b. HIT WITH STEAM AND AGITATE WITH SCRUB PAD/BRUSH OR DRILL/BRUSH COMBO
 - c. GO SLOW AND FIRM SO THE CARPET DOESN'T LOSE FIBERS AND TEAR
2. REMOVE SILK
 - a. USE MICROFIBER TOWEL AND WIPE DRY
 - b. USE A HOT WATER EXTRACTOR
3. MAKE SURE TO VACUUM

STEERING WHEEL/DASHBOARD

MOVE ON TO HIGHER STEPS IF THE PRIOR STEPS DON'T WORK

1. SPRAY CORIUM ON MICROFIBER TOWEL AND WIPE.
2. SPRAY CORIUM INTO A SOFT BRISTLE BRUSH AND AGITATE SURFACE TO RELEASE DIRT. THEN WIPE AWAY WITH MICROFIBER TOWEL.

WHEN YOU FINISH CLEANING, MAKE SURE TO MOISTURIZE WITH LUSH. SIMPLY SPRAY THE MICROFIBER TOWEL AND APPLY. WIPE AWAY ANY EXCESS.

CUP HOLDERS & CENTER CONSOLE

MOVE ON TO HIGHER STEPS IF THE PRIOR STEPS DON'T WORK

1. SPRAY CORIUM ON MICROFIBER TOWEL AND WIPE.
2. SPRAY CORIUM INTO A SOFT BRISTLE BRUSH AND AGITATE SURFACE TO RELEASE DIRT. THEN WIPE AWAY WITH MICROFIBER TOWEL.
3. WRAP STEAMER HEAD WITH MICROFIBER TOWEL AND AGITATE SURFACE. WIPE CLEAN WITH MICROFIBER OR EXTRACT.

HEADLINER

MOVE ON TO HIGHER STEPS IF THE PRIOR STEPS DON'T WORK

1. DO NOT SPRAY THE HEADLINER DIRECTLY
2. DO NOT OVER SATURATE
3. SPRAY MICROFIBER TOWEL THEN DAB SMALL SECTIONS AT A TIME.
 - a. WIPE AWAY WITH CLEAN MICROFIBER TOWEL
4. SPRAY BRUSH WITH CORIUM AND AGITATE SMALL AREAS
 - a. WIPE CLEAN WITH MICROFIBER TOWEL

FINAL CHECK

- a. DO A WALK AROUND AND GO FROM DOOR TO DOOR. CHECK EVERYTHING TOP TO BOTTOM AND INSIDE OUT. ON THE INSIDE START FROM THE CUP HOLDER AND MAKE SURE EVERYTHING IS CLEAN, AND NO STAINS RE-APPEARED.